



S1017 Y- Strainer Cleaning Procedure

PROBLEM

SOLUTION

- Water not draining from ADT (Auto Drain Trap)
- Filter of Y-Strainer get choked by rust
- If the ADT filter has not been cleaned for 15-days or more

Cleaning of Y- Strainer is required



REQUIRED TOOLS

Adjustable Spanner



ADVISORY

Before servicing, ensure isolation valve - upstream of ADT - is closed

Open the Filter of Y-stainer gets choked by rust



Remove Filter element



- Clean element using Air (if dust has accumulated) or Oil (if rust is noticed)

After cleaning, put the filter back in Y-Strainer and tighten using spanner



- Open valve for operation



PLEASE WATCH THE VIDEO, LINK BELOW

<https://youtu.be/VBDxZDzggq-c>